



Mercury™ 3000Si


Smart Programmable Encoder Systems
with High Speed Serial Word Output

*Installation Manual
and Reference Guide*



Introduction

MicroE Systems was founded to advance encoder technology to a level never before achieved. Our objective was to design encoder systems that would be small enough to fit into densely packed OEM equipment designs, affordable enough for cost-sensitive applications and easy enough to enable installation, setup and alignment by assemblers with little training. We are pleased to say that all of these goals have been realized with the introduction of the Mercury family of encoders.



Precautions



- 1 Follow standard ESD precautions. Turn power off before connecting the sensor. Do not touch the electrical pins without static protection such as a grounded wrist strap.
- 2 Do not touch the glass scale unless you are wearing talc-free gloves or finger cots. Please read this installation manual for full instructions.

LASER SAFETY INFORMATION: Mercury & ChipEncoder

This product is sold solely for use as a component (or replacement) in an electronic product; therefore it is not required to, and does not comply with, 21 CFR 1040.10 and 1040.11 which pertain to complete laser products. The manufacturer of the complete system-level electronic product is responsible for complying with 21 CFR 1040.10 and 1040.11 and for providing the user with all necessary safety warnings and information.

MicroE encoders contain an infrared laser diode or diodes. Emitted invisible laser radiation levels have been measured to be within the CDRH Class 1 range, which is not considered hazardous; however, to minimize exposure to the diverging beam, the encoder sensor should be installed in its operational configuration in close proximity to the encoder scale before power is applied.



- Invisible laser radiation; wavelength: 850 nm
- Max power 2.4 mW CW (4.8 mW CW for Mercury II™)
- CAUTION – The use of optical instruments with this product will increase eye hazard. DO NOT VIEW DIRECTLY WITH OPTICAL INSTRUMENTS (MICROSCOPES, EYE LOUPES OR MAGNIFIERS).
- All maintenance procedures such as cleaning must be performed with the MicroE encoder turned off.
- Do not insert any reflective surface into the beam path when the encoder is powered.
- Do not attempt to service the MicroE encoder.



Patents

Covered by the following patents: US 5,991,249; EP 895,239; JP 3,025,237; US 6,897,435; and EP 1,451,933. Additional patents and patents pending may apply.


Table Of Contents

SYSTEM ILLUSTRATION	PAGE
Encoder with Linear scale	2
Encoder with Rotary scale	3
INSTALLATION INSTRUCTIONS	
Encoder System Mounting - Linear	4
Encoder System Alignment - Linear	5
Centering the Index & Calibration - Linear	5
Encoder System Mounting - Rotary	6
Encoder System Alignment - Rotary	7
Centering the Index & Calibration - Rotary	7
REFERENCE SECTION	
Installation of Linear Scales	8
Grounding Instructions	9
Recommendations for Power	9
Customer Interface Cable Requirements	10
SmartPrecision™ Module Mounting Options	11
SERIAL OUTPUT SPECIFICATION	12-16
ENCODER TROUBLESHOOTING	
Selected Topics	17
Cleaning Scales	17
Contact MicroE Systems	Back Cover


Mercury 3000Si Encoder System with Linear scale



Mercury 3000Si Encoder System with Rotary scale



Expanded View



Installation Instructions

Linear Encoders

1 Attach the scale to the base slide. Reference the preferred datum on the interface drawing for either end or center index orientation.


Depending on the mounting method, attach the scale to the slide with adhesive. Refer to pg. 8 for details.

Be sure the grating surface of the scale faces the sensor. Insure that there is no contact between these surfaces or damage may result.

2

Install the sensor on your mounting surface referencing the appropriate datum surface as shown on the interface drawing. Use 2 washers per mounting screw.

Benching pins may be used to locate the sensor if the system mechanical tolerances are adequate. See data sheet for alignment tolerances, or keep mounting screws loose for sensor alignment if benching pins are not used.



4

Be sure the source power is off before connecting the SmartPrecision plug.

Connect the SmartPrecision electronics to the controller using the pinout diagram described on the interface drawing.

Pin 1 must not be connected under any circumstances, including connection to wires within extension cables and floating wires. Any connection to Pin 1 could damage or disable the encoder system.

Insure proper system grounding. Refer to the procedure on pg 9.

Tighten the thumb screws.

Power up the system. The Power/Calibration indicator will illuminate.

3


CAUTION: observe precautions for handling electrostatic sensitive devices.

Route the sensor cable through your equipment to the SmartPrecision electronics.

A) Remove the three cover screws and the top half of the connector housing. Do not pull on the 15-pin D-sub connector or the circuit board under the insulation layer.

B) Attach the sensor's 5 X 2 connector to the mating 5 X 2 connector on the circuit board.

C) Route the sensor cable through its channel in the center of the connector body and place the cable's hex sleeve in the matching recess. Attach the top half of the connector housing to the bottom half using the three cover screws.



Installation Instructions


Linear Encoders

If benching dimensions cannot be provided, proper sensor alignment may require minor adjustments to the sensor position with respect to the scale. This can be performed easily using the LED alignment indicators, as illustrated below.


5

The red, yellow, or green LED will light depending on sensor alignment. Slowly move the sensor by allowing it to slide on the mounting surface until the green or Proper Alignment LED, is illuminated. Optimal alignment will be displayed as a "Bright Green" LED.

IMPORTANT: Confirm that the Proper Alignment LED blinks when passing over the index. If not, readjust the sensor in the Y direction and repeat the above procedure. When alignment is completed, tighten the sensor mounting screws (0.37Nm [3.3 inch-lbs.] maximum torque).




To align the sensor, move it in the Y or θ_z directions.



6

Confirm proper alignment over the full range of motion. The "Proper Alignment" LED must remain on over the entire range. If not aligned over the entire range of motion, loosen the sensor mounting screws and repeat step 5.




7

IMPORTANT **OUTPUT CALIBRATION PROCEDURE**

This procedure must be completed for proper system operation each time the sensor is aligned or if the SmartPrecision electronics module is replaced

Position the sensor at least 7mm (1/4") away from the index mark on the scale. Next, push the Index/Calibration button inside the module with a small diameter shaft, such as a bare cotton swab.




The Power/Calibration indicator will flash continuously. Move the scale past the sensor in both directions so that the index mark passes under the sensor. When the calibration procedure is complete, the Power/Calibration indicator stops flashing.

Installation Instructions

Rotary Encoders

1


Attach your hub/scale assembly to the rotary device. Refer to the interface drawing. The reflective surface of the scale must face the sensor.



2

Install the sensor on your mounting surface referencing the appropriate datum surface as shown on the interface drawing. Use 2 washers per mounting screw.

Benching pins may be used to locate the sensor if the system mechanical tolerances are adequate. See data sheet for alignment tolerances, or keep mounting screws loose for sensor alignment if benching pins are not used.



4

Be sure the source power is off before connecting the SmartPrecision plug.

Connect the SmartPrecision electronics to the controller using the pinout diagram described on the interface drawing.

Pin 1 must not be connected under any circumstances, including connection to wires within extension cables and floating wires. Any connection to Pin 1 could damage or disable the encoder system.

Insure proper system grounding. Refer to the procedure on pg 9.

Tighten the thumb screws.

Power up the system. The Power/Calibration indicator will illuminate.

3


CAUTION: observe precautions for handling electrostatic sensitive devices.

Route the sensor cable through your equipment to the SmartPrecision electronics.

A) Remove the three cover screws and the top half of the connector housing. Do not pull on the 15-pin D-sub connector or the circuit board under the insulation layer.

B) Attach the sensor's 5 X 2 connector to the mating 5 X 2 connector on the circuit board.

C) Route the sensor cable through its channel in the center of the connector body and place the cable's hex sleeve in the matching recess. Attach the top half of the connector housing to the bottom half using the three cover screws.



Installation Instructions


Rotary Encoders

If benching dimensions cannot be provided, proper sensor alignment may require minor adjustments to the sensor position with respect to the scale. This can be performed easily using the LED alignment indicators, as illustrated below.




5

The red, yellow, or green LED will light depending on sensor alignment. Slowly move the sensor by allowing it to slide on the mounting surface until the green or Proper Alignment LED, is illuminated. Optimal alignment will be displayed as a "Bright Green" LED.

IMPORTANT: Confirm that the Proper Alignment LED blinks when passing over the index. If not, readjust the sensor in the Y direction and repeat the above procedure. When alignment is completed, tighten the sensor mounting screws (0.37Nm [3.3 inch-lbs.] maximum torque).




To align the sensor, move it in the Y or θ_z directions.



Confirm proper alignment over the full range of motion. The "Proper Alignment" LED must remain on over the entire range. If not aligned over the entire range of motion, loosen the sensor mounting screws and repeat step 5.

6



7


IMPORTANT

OUTPUT CALIBRATION PROCEDURE

This procedure must be completed for proper system operation each time the sensor is aligned or if the SmartPrecision electronics module is replaced.

Position the sensor at least 7mm (1/4") away from the index mark on the scale. Next, push the Index/Calibration button inside the module with a small diameter shaft, such as a bare cotton swab.

Power/
Calibration
indicator
Calibration /
Index Set
Up button
Proper
Alignment
indicator



The Power/Calibration indicator will flash continuously. Move the scale past the sensor in both directions so that the index mark passes under the sensor. Do not run off the end of the scale when using a segment scale. When the calibration procedure is complete, the Power/Calibration indicator stops flashing.

Reference Section

Installation of Linear Scales

Positioning the Scale


Note: Before beginning mounting procedure, use talc-free gloves or finger cots to handle the scales.

"Benching" the scale to the system means aligning the scale by means of benching pins. Pin locations are described on the appropriate interface drawing.

Two benching pins are recommended on the long side of the scale and one at the end as shown. This is marked datum A on the interface drawing.

1 Position the benching pins in from either end. 20% of the overall scale length is the recommended location from the edge.

2 Be sure the benching pins do not extend too high in the Z direction to prevent mechanical interference with the sensor or sensor mount.



Mounting the Scale

MicroE Systems' linear scales should be affixed to the mounting surface. Two different approaches are described below:

Epoxy and RTV Mounting (Recommended for best accuracy)

1 Make sure the mounting surface is clean and dry.

3 Optionally, scale clamps may be used to secure the scale while the adhesive cures. Avoid damage to the top surface.

2 Align the scale by placing the edges against the benching pins.

4 Apply a hard epoxy, such as Tra-Con's Tra-Bond 2116, to the end of the scale at the end benching pin. Apply 100% Silicone RTV adhesive around the edges of the scale. This method allows thermal expansion from the benched end of the scale. After adhesive curing, remove the scale mounting clamps or, if permanently installing clamps, make sure they do not interfere with the sensor or sensor mount.

End Benching Pin

Hard epoxy at one corner, this end only.

Mounting clamp

L

Benching pins

RTV around entire outside edge of scale.


Scale clamp with adhesive

Side view showing optional scale clamps and scale. Space clamps every 75mm on scales over 150 mm in length.

Two Sided Adhesive Tape Mounting

1 Make sure the mounting surface is clean and dry. Peel the cover paper off and place the scale above the final location.

3 Gently place the scale on the mounting surface. Positioning adjustments can be made until the scale is firmly pressed down. After final positioning, push down on the top of the scale to secure it.




Grounding Instructions for Mercury 3000Si Encoder Systems

For Mercury 2000 and 3000 encoder systems to operate reliably, it is essential that the sensor and cable shield are grounded properly according to the following instructions. The diagrams below show how to make the connections when the encoder's connector is plugged into the customer's controller chassis. If a customer-supplied extension cable is used, it should be a double shielded cable with conductive connector shells and must provide complete shielding over the conductors contained within it over its entire length. Furthermore, the shields should be grounded at the connection to the controller chassis the same way as the encoder connectors in the diagrams below.

Note: For best performance, isolate encoder shield from motor cable shields and separate encoder cable as far possible from motor cables.


Sensor mounted with good electrical contact to a well-grounded surface (preferred)

1. 15-pin D-sub connector grounding: The encoder's connector shell must be in intimate, electrically conductive contact with the customer-supplied mating connector, which must be isolated from the controller's ground. If a customer-supplied shielded cable connects the encoder to the controller, then the shielding on the customer-supplied cable must be isolated from the controller's ground.
2. The sensor mounting surface must have a low impedance (DC/AC) connection to ground. The encoder sensor mounting surface may have to be masked during painting or anodizing to insure good electrical contact with the sensor.



Sensor mounted to a surface that is grounded through bearings or a poorly-grounded surface, or a non-conducting surface

1. 15-pin D-sub connector grounding: The encoder's connector shell must be in intimate, electrically conductive contact with the customer-supplied mating connector, which must be connected to the controller's ground. If a customer-supplied shielded cable connects the encoder to the controller, then the shielding on the customer-supplied cable must be connected to the controller's ground. The controller must be grounded to earth at the point of installation.
2. The encoder sensor must be mounted so that it is electrically isolated from ground.



Recommendations for Power

Mercury encoders require a minimum of 4.75V DC continuously. When designing circuits and extension cables to use Mercury encoders, be sure to account for voltage loss over distance and tolerances from the nominal supply voltage so that at least 4.75V DC is available to the Mercury encoder under all operating conditions. The input voltage should not exceed 5.25V DC.

Customer Interface Cable Requirements

Customer cables that interface to Mercury series encoders must have the following characteristics:

- Twisted pair signal wiring.
- Characteristic impedance of 100-120 ohms.
- Sufficient wire gauge to meet the minimum voltage requirement at the encoder, for example 24AWG gauge wire for a 2m length cable. Examples of acceptable cables with 24 AWG gauge wire and 5 twisted pairs are Belden 9832, 8105 or other manufacturer's equivalents.
- Single shield cable with a minimum of 90% coverage. Note that a double shielded cable may be required in high-noise applications.

Signal Wiring:


Each differential signal should be connected to a corresponding twisted pair as follows:

Mercury 3000Si	
Signal	Twisted Pair
SD0+	Pair 1
SD0-	
Trigger+	Pair 2*
Trigger-	
SCK+	Pair 3
SCK-	
N_CS+	Pair 4
N_CS-	
+5V	Pair 5
GND	

* For synchronous system connection only.

Shield Termination:


The customer's cable shield should be in 360° contact with the connector shroud and the connector shell to provide complete shielding. The connector shell should be metal with conductive surfaces. Suggested metal connector shells for use with Mercury 3500, 3000, 3000Si, and 2000 encoders: AMP 748676-1 or equivalent; for Mercury 1000 and 1500S encoders: AMP 745172-3, -2, or -1 where the dash number is dependent on the customer's outside cable diameter. The shield should be terminated as illustrated in the following diagram.



Fold braided shield back over jacket. Example shows double-shielded cable. Dimensions shown are for illustration only.

Reference Section

SmartPrecision Module Mounting Options



The SmartPrecision electronics module may be mounted directly to a bulkhead connector using the integral thumb screws shown in figure A.

Alternatively, the module may be used with an extension cable and mounted to a base plate using the mounting tabs as shown in figure B.

Serial Output Specification

Introduction

Historically, the method of choice for many optical position feedback systems has been A quad B (Quadrature) output. The limitation of this method is output speed, especially when the interpolation level is high. When the optical sensor speed and/or the interpolation multiplier is set high, the Quadrature output frequencies will be extremely high and out of the range of the Quadrature counters of most standard motion controllers.

This limitation can be avoided by sending the position information in parallel format or in a serial word format. The parallel formats are cumbersome to cable (especially wide word lengths) and are more susceptible to noise interference. Therefore, a serial data word format is the data communication method of choice.

The Mercury 3000Si Interpolator has the ability to output a position word in a serialized format. This allows very fast communication between an interpolator and customer application. The speed limitation of the Quadrature format is thus eliminated.

Signal Description

The interface from your electronics to the Mercury 3000Si interpolator uses four signals, n_spiEnable (n_CS), spiDataOut (SDO), spiClock (SCK), and optional spiTrigger (TRIG). Each signal is differential and RS-422 compatible. See table for interpolator signal names, pin names, and pin locations:

Signal Description

Signal name	Pin Name	Function	I/O Interpolator Referenced	15 pin HD Connector
n_spiEnable	n_CS+	Chip Select+	Input	7
	n_CS-	Chip Select-	Input	8
spiClock	SCK+	Serial Clock+	Input	14
	SCK-	Serial Clock-	Input	15
spiDataOut	SDO+	Serial Data Out+	Output	5
	SDO-	Serial Data Out-	Output	4
spiTrigger	TRIG+	External Trigger+	Input	10
	TRIG-	External Trigger-	Input	9

Serial Output Specification


SmartPrecision 3000Si Interpolator Operation

Standard Communication Approach

Asserting the `n_spiEnable` signal freezes the current position word and status information within the interpolator. The serial data is valid 85ns (max.) after the assertion of `n_spiEnable` signal. The `n_spiEnable` signal is kept asserted while `spiClock` signal toggles out the data. Each serial data bit is valid on the falling edge of the clock signal. A high to low transition of the `n_spiEnable` signal must be accomplished between acquisitions to allow the internal serial data buffer to update with new information.

Note: The timing diagram information described here lists the timing delays between a request for data at point A and the receipt of data at point B in the Delay diagram. It does not include the interface cable, line drivers/receivers or any other electronics needed at the customer interface for signal acquisition.


Timing Diagram



Timing Symbol Description

Symbol	Parameter	Minimum	Typical	Maximum	Units
t_{spiH}	SCK High Time	50			ns
t_{spiL}	SCK Low Time	50			ns
t_{CSD}	<code>n_CS</code> to DataValid		65	85	ns
t_v	↓SCK to Data Valid		65	85	ns
t_{CCS}	SCK to <code>n_CS</code>	0			ns
t_{CS}	<code>n_CS</code> High	208			ns
t_{DNA}	<code>n_CS</code> to HiZ		35	50	ns

Timing Schematic of Worst-Case Delays




Trigger Communication Approach

The Trigger Approach can be used in applications where synchronization of the position data to an event is required. Often, this approach is used when a fixed latency between a clock signal and the sampled position data is required. The customer chooses this method of operation by using the spiTrigger signal. The spiTrigger signal starts the process by immediately resetting the internal calculators and acquiring the latest AD converter information. Old data in the calculation chain is discarded and the initiation of a new position calculation is started. The new data is ready in 734ns. The n_spiEnable signal must be asserted within 209ns after the data is ready. In the figure below, n_spiEnable must be asserted between 734ns and 942ns after spiTrigger. If this does not occur, synchronization will be lost.

At this point, shifting the data out of the interpolator's serial port is accomplished exactly as in the standard mode of operation. In order to sample the next position, n_spiEnable must be brought high and spiTrigger asserted again. See the Trigger Approach timing diagram below.

Trigger Approach Timing Diagram



Timing Signal Description

Symbol	Parameter	Minimum	Typical	Maximum	Units
tspiH	SCK High Time	50			ns
tspiL	SCK Low Time	50			ns
tTDR	TRIG to DataReady	734		903	ns
tW	TRIG width	25			ns
tCSD	n_CS to DataValid		65	85	ns
tV	↓SCK to Data Valid		65	85	ns
tCCS	SCK to n_CS	0			ns
tCS	n_CS High	208			ns

Serial Output Specification

Important Notes

There is a latency of 734ns in the position calculator so the user must wait this amount of time after sending the trigger to acquire the correlating position data. Also, the calculation pipeline is 209ns between updates so after the latency the user has 209ns to freeze the synchronous data by asserting the n_spiEnable before the position calculation is updated. If the user waits longer than 208ns after the end of tTDR, then the interpolator's output buffer will contain data from a later sample that has not been synchronized with spiTrigger.

When in the synchronous mode of operation the spiTrigger is sampled by an internal clock. The uncertainty of this measurement is 20ns.


When in the standard mode of operation no synchronization of the interpolator calculation is made to an external event. This means that from an assertion of the n_spiEnable signal to another assertion of the n_spiEnable signal there is a 208ns measurement uncertainty.

Data Format

The data word, which includes the position and status words, is transferred with the most significant bit (MSB) first. The data word length is up to 36 bits long. The most significant 8 bits are the status word. The next 28 bits are the position word. This position word is large enough to keep track of a grating length of 5.24 meters. The interpolation depth of the SS-300cSi always 1024. If the user prefers smaller interpolation depths then fewer spiClock signal clocks can be sent to the interpolator and fewer bits will be shifted out.

Status Word Definition

Byte Values	Signal Names	Descriptions
0000_0011	Operational Mode	Normal Mode
0000_0010	Red Alarm Signal	Level Error
0000_0001	Yellow Alarm Signal	Level Warning
0000_0111	Index Mode	Firmware in index finding mode
0000_1011	Index Window	Encoder is within physical index window



Index Processing

A unique physical position is referenced on all gratings and is called an index position. The value of this position is determined during an index capture routine initiated by a button press or the SmartPrecision Software and is permanently stored for use after power cycling. The index value has the same resolution as the interpolated position.

The SS-300cSi has four modes of operation that use the index position to generate a physical reference position. The position word calculated by the SS-300cSi electronics is a 28-bit number, which includes 18 fringe counter bits and 10 sub-fringe interpolation bits. The fringe counter keeps track of the number of electrical cycles encountered caused by a grating moving past a sensor and can be reset. The sub-fringe position is absolute because the voltage relationship between sine and cosine are fixed electrically and therefore cannot be reset or cleared.

A physical mark on the grating called an index window is used to generate an accurate index position. The index window is approximately one fringe wide. By monitoring the edges of the window with respect to the absolute sub-fringe position during the index capture mode, an accurate index position is calculated and stored.

At power up the encoder is in an undefined position relative to the outside world. By traveling past the index mark on the scale and knowing where the index is relative to the outside world the encoder position becomes defined. The M3000Si supports the following index processing modes:

No Index: No changes are made to the position word at the index mark.

Mode 1: Zeros the fringe counter at the first encounter with index mark after power up.

Mode 2: Zeros the fringe counter at every encounter with index mark.

Mode 3: Zeros the fringe counter at the first encounter with index mark after power up and subtracts the index position from the calculated position making the index mark the zero position of the encoder.

Mode 4: Zeros the fringe counter at every encounter with index mark after power up and subtracts the index position from the calculated position making the index mark the zero position of the encoder.

The Index mode can be factory set or selected by the customer using the optional SmartPrecision software.

Troubleshooting

Problem

The Power/Calibration indicator will not come on.

Solution

- Make sure that the SmartPrecision electronics' 15-pin HD connector is fully seated and connected.
- Confirm that +5 Volts DC is being applied to pin 12 on the SmartPrecision electronics' 15-pin HD connector and that pin 13 is connected to ground.

Problem

None of the SmartPrecision electronics' LEDs turn on.

Solution

- Refer to the Grounding Reference Guide on pg. 9.

Problem

Can't get the SmartPrecision electronics' "Signal" LEDs better than red or yellow; or the green, " Proper Alignment" indicator doesn't stay illuminated over the full length of the scale.

Solution

- Verify that the sensor head has been aligned to the scale and that the mounting screws are tight. Check the dimensions for the mechanical mounting holes (and clamps if any) to make sure that the sensor is correctly located over the scale. Refer to appropriate the interface drawing.
- Check that the scale is firmly mounted and can't jiggle or move in other than the intended direction.
- Make sure that the scale is clean over its entire length or circumference.

Problem

The green Power/Calibration indicator is flashing unexpectedly.

Solution

- Part of the normal setup procedure is to activate the SmartPrecision electronics' index capture process by pressing the recessed button on the SmartPrecision electronics' connector body. The On/Index LED will begin to flash until the index mark on the scale passes under the sensor at least one time in each direction.

Problem

Can't complete the Capture Index process - the green Power/Calibration indicator doesn't stop flashing.

Solution


- Verify that the sensor is mounted in the correct orientation to the scale for the desired index mark. Refer to the interface drawing.
- Refer to step 5 of the installation procedure to insure proper operation.

Cleaning scales



General Particle Removal

Blow off the contamination with nitrogen, clean air, or a similar gas.



Contamination Removal

Use a lint-free cleanroom wipe or cotton swab dampened with isopropyl alcohol or acetone only. Handle the scale by the edges. Do not scrub the scale.

Contact MicroE Systems

Thank you for purchasing a MicroE Systems product. You should expect the highest level of quality and support from MicroE. If you want to download the Mercury Encoder Installation Manual, Data Sheet or Interface Drawing, browse www.microesys.com and click on the Mercury Encoders button.

